

NOTE 1: SOME OF THE CIRCUITS SHOWN HERE WILL NOT BE ACTIVE IN ALL APPLICATIONS. CONSULT THE EQUIPMENT MANUFACTURERS LITERATURE TO DETERMINE WHICH CIRCUITS ARE USED.

NOTE 2: MAY BE EITHER INCREMENT OR DECREMENT DEPENDING ON THE VALUE OF THE ECM ADJUSTABLE PARAMETER "CRUISE CONTROL SETUP".




OEM RESPONSIBILITY

CUMMINS RESPONSIBILITY

ELECTRONIC CONTROL MODULE OEM CONNECTOR



ELECTRONIC CONTROL MODULE ENGINE HARNESS CONNECTOR



PROOF COPY
Bulletin 4021626-01
2/23/2010

CUMMINS CONFIDENTIAL
DRAFT COPY

OEM RESPONSIBILITY

CUMMINS RESPONSIBILITY